
ASM330LHBxx_ASILB_library safety manual

Introduction

This application note provides guidelines and recommendations for the proper use of the safety software library (ASM330LHBxx_ASILB_library) referred to as "safety engine" throughout this document. This library is used in target ASIL-B applications that need information about the linear accelerations and angular rates of the vehicle, like in-dash car navigation, accurate positioning, V2X (vehicle-to-everything), radar, lidar, and camera stabilization systems or others.

More specifically, the safety engine is intended as a *Safety Element out of Context (SEooC)* and it is developed according to ISO26262-6.

The notation ASM330LHBxx refers to the IMU sensors with product names ASM330LHB and ASM330LHBG1, and it is used to reference both devices.

This application note clarifies how safety boundaries and behavior have been conceived, and how the entire safety flow has been followed from the assumed item to the SEooC software safety requirements, available and strictly related to the proposed SEooC architecture (refer to [Section 1.1: SEooC architecture](#)), not including all other components, PCB design and layout of traces, vias and ground plane.


To allow an analysis of the safety engine capability to reach the required safety level, assumptions have been made, following the concept of SEooC described in the ISO26262.

1 SEooC overview

1.1 SEooC architecture

The system block diagram where the safety engine is developed as an SEooC is shown in [Figure 1](#) and it is made up of the following building blocks.

Figure 1. System block diagram in which the SEooC has been developed



- Two identical sensors (redundancy of IMUs), properly supplied, provide information to the system about the linear acceleration along the axes of the module where the sensors are mounted, hence of the car, and the angular rate of the axes of the car.
- A host processor, properly supplied, is connected to a subsequent elaboration path and it has an interface suitable for the communication with the two IMUs.
- A communication bus allows communication between the host processor and the two IMUs.
- The safety engine running on the host processor, which communicates with the two IMUs through the host processor communication interface and which includes the drivers for the correct use of the two IMUs. The safety engine embeds the safety mechanisms designed to meet the technical safety requirements.
- The output of the safety engine, which is the input of the SMU inside the host processor.

1.2 Basic assumptions

The safety engine has been developed based on the following assumptions:

Assumption #1: It is assumed that the system in which the SEooC is included requires that the SEooC itself is a safety level of ASIL-B.

Assumption #2: It is assumed that the integration of the software into the MCU, or application specific processor, meets the requirements given in [Section 2.5.2: Software freedom from interference](#).

Assumption #3: It is assumed that the architecture of the SEooC, described in this document, will not be modified or compromised in the application.

Assumption #4: It is assumed that the customer's design, using the safety engine, fulfills specific safety manual (SM) assumptions and requirements. If the customer's design does not fully comply with the assumptions, the customer must show an alternative solution similarly efficient concerning the safety requirements.

Assumption #5: It is assumed that the component does not compromise the operating conditions of the safety engine, if any component is interposed between the IMUs and the safety engine in the host processor.

Assumption #6: It is assumed that all relevant safety mechanisms are enabled and configured according to the information reported in this document.

Assumption #7: It is assumed that electronic control unit network environments (refer to Table 13 of ISO 26262-6:2018, 11.4.1) are not considered when verifying that the embedded software fulfills the software safety requirements in the target environment. The execution of these tests is left to the system integrator to ensure coherency to the overall concept.

Assumption #8: It is assumed that the safety engine works with two identical IMUs, called ASM330LHBxx.

Assumption #9: It is assumed that the system integrator verifies the compliancy of ASM330LHBxx with ISO26262-5, by evaluating the hardware according to ISO 26262-8:2018(E) clause 13 as a class II component off the shelf and knowing that ASM330LHBxx is a hardware element not developed according to ISO26262.

Assumption #10: It is assumed that independently from the specific item, IMUs ASM330LHBxx are primarily adopted to provide the measurements of acceleration and angular rates to vehicle electronic control units.

Assumption #11: It is assumed that the IMUs are exposed to the same environmental and operational conditions they are intended for, according to what is stated in the datasheet.

2 Safety concept

In this section, the safety analysis at vehicle level is assumed, based on the result typically created by the OEM and partially provided to a supplier. Malfunctions and hazards are reported in the assumed HARA analysis, for which a global ASIL (B) evaluation is available.

The following outcome relates to the generic item considered, acting at system level (vehicle) independently from any other host source input.

Note: *In the safety concept, the actions of the driver are not part of the system inputs, which means that the driver is not included as part of the functional safety concept. As a consequence:*

- *Reaction of the user in warning indications is not considered.*
- *Possibility of function override by the driver is not applicable.*

2.1 Assumed safety goals

The following hazards and attributes are identified as the output of an assumed hazard and risk assessment, related to the SEooC architecture shown in [Figure 1](#).

Assumption #12: It is assumed that the HARA at vehicle level is already produced by the system integrator. Safety goals and safe states are defined at item level for the specific item in which the SEooC is included. At the boundary of the SEooC, safety goals are assumed, considering a portion of the system (shown in [Figure 1](#)) to be integrated in the overall item at vehicle level, and are defined here for functional purposes, with assumed inherited ASIL evaluation and DTTI.

Note: *The “diagnostic test time interval” (DTTI) is used instead of “fault tolerance time interval” (FTTI) at this level of hierarchy because part of the whole FTTI budget for failure notification at system level could include other activities, which might also require some time to be performed.*

Diagnostic test time: 100 ms. It is assumed that the end user of the IMU verifies the compliancy of such limit to the final application.

Assumption #13: It is assumed that:

- **Safety goal:** To prevent that information relative to acceleration and angular rate are passed as inaccurate or are not passed to the following modules of the elaboration chain.
- **Safe state:** The safety engine shall identify occurrences of IMU faults and alert the system hosting the library with a flag/alarm mechanism.
- **Diagnostic test time:** 100 ms. It is assumed that the system integrator verifies the compliancy of such limit to the final application.

2.2 Failure mode analysis

The following malfunction related to the safety engine is identified:

- **MF01:** Failure of the safety engine
Output is corrupted, degraded, or absent.

Assumption #14: It is assumed that, corresponding to the assumed safety goal and the preliminary architecture depicted in [Figure 1](#), the following set of malfunctions and failures are valid:

- **MF02:** Failure of the communication interface
SPI/I²C communication is corrupted or absent, ports are defective, or a high rate of packet loss is verified.
- **MF03:** Failure of the power supply
Power supply is absent, or it is not stable.
- **MF04:** Failure of the IMU raw measurement
The safety engine cannot process raw data because absent or corrupted.

Based on the considerations proposed so far, it is assumed that the SEooC safety goal can be allocated as a single top-level requirement defined as below.

ID	SR_01
Description	The safety engine shall always provide a reliable and accurate measurement of acceleration and angular rates from the IMUs. Otherwise, it notifies through an error code.
Safe state	Notification at the output of the safety engine
DTTI	100 ms

The assumed safe state is the notification at the boundary of the SEooC, meaning that the final target of the integrated software module is for diagnostics/monitoring duties. Failure avoidance mechanisms are not considered.

Assumption #15: It is assumed that reactions to error flags raised by the library are managed at integration level and that the output data of the library, in the presence of an error flag, is not considered as valid data.

2.3 Assumed functional safety requirements

Based on the information relative to the SEooC safety goals and safe states, it is possible to derive the functional safety concept. Its target is to define the appropriate safety functions able to fulfill the safety goals and to allocate these safety functions to the elements of the preliminary architecture.

The results in the functional safety requirements and the functional safety architecture that can be derived from it are indicated in the following tables.

ID	FSR_01
Description	The safety engine integrated in the host processor shall receive (<i>that is, data is present</i>) input data from the IMU subsystem. Communication shall be verified.
TSR items	<ol style="list-style-type: none"> 1. SPI/I²C interface check (communication and packet loss) 2. Port electrical check 3. IMU detection and data availability → for example, WHOAMI check
Motivation	Continuous availability of input data from both IMUs shall be verified.
Safe state	Fault indication and/or invalid data
Validation criteria	It shall be validated by specific validation test cases on the embedded platform.

ID	FSR_02
Description	The safety engine shall always provide input data to the SMU integrated in the host processor.
TSR items	<ol style="list-style-type: none"> 1. Datasheet specification check 2. IMU detection and data availability → for example, WHOAMI check 3. Software block diagnostics
Motivation	The correct functioning of systems using the IMU depends on the accurate input data from the IMU modules.
Safe state	Fault indication and/or degraded output data
Validation criteria	It shall be validated by specific validation test cases on the embedded platform.

ID	FSR_03
Description	The safety engine integrated in the host processor shall receive RELIABLE input data from the IMU. This reliability has to be checked.
TSR items	<ol style="list-style-type: none"> 1. Data integrity 2. Data accuracy 3. Information about data integrity and data accuracy
Motivation	Accuracy of the safety engine output relies on the availability of accurate and correct input data from IMU modules, with guarantee of the accuracy level.
Safe state	Fault indication with specific FLAG
Validation criteria	It shall be validated by specific validation test cases on the embedded platform.

Note: *RELIABLE input data are intended as data that respect datasheet parameters and also that represent proper device functionality (expected output of the motion sensor submitted to certain stimulus conditions).*

2.4 Assumed technical safety concept

The technical safety concept relies on the inputs derived from the functional safety requirements and the assumptions of the preliminary architecture. Safety mechanisms are defined as well as the technical safety requirements.

Based on the listed FSR requirements and the inputs from selected customers, the following technical safety requirements (TSR) are assumed. At this level, it is possible to identify the specific requirement related to the software domain, explicitly derived from TSR IDs.

ID	TSR_01_01_SW					
Description	The safety engine shall check the presence of an IMU subsystem.					
Safe state	Fault indication and/or invalid data					
ASIL	B	FTTI	100 ms	Status	Accepted	

ID	TSR_03_01_SW					
Description	The safety engine shall return verified data to the SMU integrated in the host processor.					
Safe state	Fault indication with specific FLAG					
ASIL	B	FTTI	100 ms	Status	Accepted	

ID	TSR_04_01_SW					
Description	The safety engine shall check the integrity of input data from the IMU subsystem.					
Safe state	Fault indication					
ASIL	B	FTTI	100 ms	Status	Accepted	

ID	TSR_04_02_SW					
Description	The safety engine shall check the accuracy of input data from the IMU subsystem.					
Safe state	Fault indication					
ASIL	B	FTTI	100 ms	Status	Accepted	

ID	TSR_04_03_SW					
Description	The safety engine shall return an informative measure on the reliability and accuracy of the IMU subsystem input data.					
Safe state	Fault indication					
ASIL	B	FTTI	100 ms	Status	Accepted	

Assumption #16: It is assumed that the following technical safety requirements concerning the hardware part are assumed and shall be validated by specific test cases accepted by the system integrator for the specific embedded architecture:

ID	TSR_01_01_HW					
Description	The SPI/I ² C interface must be validated in terms of overall functionality and packet loss rate.					
Safe state	Fault indication and/or invalid data					
ASIL	B	FTTI	100 ms			

ID	TSR_01_02_HW			
Description	The SPI/I ² C ports and pins must be verified.			
Safe state	Fault indication and/or invalid data			
ASIL	B	FTTI	100 ms	

ID	TSR_02_01_HW			
Description	Vdd and Vdd/IO lines shall guarantee the correct power supply voltage to the IMU subsystem.			
Safe state	Fault indication and/or invalid data			
ASIL	B	FTTI	100 ms	

ID	TSR_02_02_HW			
Description	Vdd and Vdd/IO ports must be verified.			
Safe state	Fault indication and/or invalid data			
ASIL	B	FTTI	100 ms	

2.4.1 Allocation of safety requirements

In relation to the FSR/TSR trace, the following table lists the hierarchical reference.

FSR ID	TSR ID
FSR_01	TSR_01_01_SW
FSR_02	TSR_03_01_SW
FSR_03	TSR_04_01_SW
	TSR_04_02_SW
	TSR_04_03_SW

2.5 Avoidance of systematic failures

Software is developed compliant to ISO2626-part6 in order to minimize the occurrence of systematic failures. In particular, the activities, the documentation flow, and the life cycle of the products are fully managed, ensuring that processes, people, and tools are properly managed according to the ISO specification.

2.5.1 Software failure modes and ISO coding guidelines

The library has been developed, taking into account the software failure modes through the safety analysis produced. The minimization of fault propagation at software level is pursued with the exploitation of coding guidelines defined in accordance with ASIL-B requirements. An extract of these rules is indicated in the following table.

Table 1. Extract of coding guidelines

ID	Description
Safe_code_X	One entry and one exit point in all functions
Safe_code_Y	Restricted use of pointers
Safe_code_Z	No implicit type conversion
Safe_code_XX	No recursion
Safe_code_YY	MISRA_C coding rules
Safe_code_ZZ	McCabe number < TH for each single module

During software development, safety analyses and verifications have been produced:

- SW-DFA (FFI) and generated assumptions for safety integration
- SW-HAZOP and SW-FMEA at the architecture/design level
- Static code analysis at unit design / code implementation level
- Dynamic code coverage at testing level

2.5.2 Software freedom from interference

Software has been evaluated and analyzed in relation to the interference failure modes, associated to the library integration in the host processor. These failure modes include:

- *Code failures*: faulty software modifies executable code.
- *Data failures*: faulty software or falsely configured bus masters (DMA) could write to variables, parameters, heaps, and stacks.
- *Hardware resource*: faulty software or falsely configured bus masters (DMA) could write to configuration registers and hardware devices.
- *Program control flow*: faulty software modifies the sequence of other safety software, for example, corrupting interrupt vectors, TCB, stack, missing restore of registers and flags.
- *Time*: faulty software influences the correct timing of safety software, for example, by blocking resources, high frequency of context switches and soft-interrupts.

Software safety mechanisms to cope with these failures have been included, and additional assumptions are derived for the system integrator because at library level any possible control/avoidance measure has been evaluated as unachievable.

2.6 Random failure modes and safety mechanisms

Starting from the list of malfunctions, it is possible to refine the group of failure modes associated to the ASM330LHBxx sensor. Contributions to this refinement include inputs from different customers and internal analysis.

Based on the derived safety goals, failure modes can generate three groups of hazards (H1, H2, H3): data availability, data integrity, and data accuracy. For each of these groups, faults are listed:

- **H1. Data availability**
 - *Data loss, communication interface fault*
 - *Deviation in actual sample rate with respect to the set*
 - *Uncontrolled reset*
- **H2. Data integrity**
 - *Register corruption*
 - *Stuck and quasi-stuck output*
- **H3. Data accuracy**
 - *Full-scale fault*
 - *Bias/ZRL out of spec*
 - *Pulse transitions*
 - *Redundancy*

For the sake of clarity, let's introduce additional assumptions:

Assumption #17: It is assumed that the system where the SEooC is included has the capability of reading the output of the safety engine.

Assumption #18: It is assumed that the list of implemented safety requirements and safety mechanisms covers all the identified failures for the system under consideration. Moreover, communication failures are in part requested by the host, so that, in this regard, the loss of communication and message corruption is analyzed.

3 Software development

This section provides details on the software requirements and associated safety mechanisms implemented within the safety library as well as detailed information on faults covered.

The list of top-level software requirements is summarized in [Table 2. SEooC high-level software safety requirements](#), low level requirements are derived from splitting each of the entries in requirements addressing each specific failure mode that should be covered by a dedicated safety mechanism. In this sense, it is clear from a functional perspective the equivalence between low-level software requirements and software safety mechanisms. The entire list of software requirements inherits the same ASIL per the discussions provided above within FSC and TSC. The alignment with the ISO26262 and QMS processes is then approached to ensure overall ASIL-B compliancy.

Table 2. SEooC high-level software safety requirements

SEooC safety requirement ID	SEooC safety requirement	TSR reference	SEooC functionality
SW_REQ_01	IMU information is present and verified by the safety engine [presence]	TSR_01_01_SW	The safety engine shall check the availability of data from the IMUs and alert if the connection is lost or the data is missing. This can be verified with: <ul style="list-style-type: none"> • WHOAMI check • Safe read/write • Refresh of registers
SW_REQ_02	Data from IMU shall be correct and in line with the datasheet, at the startup of the system [integrity]	TSR_04_01_SW	The safety engine shall verify the integrity of input data from the IMU at startup. Integrity can be verified based on: <ul style="list-style-type: none"> • Output data register checks • Control register checks • OTP registers • Data checks during stationary conditions
SW_REQ_03	Data from IMU shall be continuously verified in terms of integrity and correctness during normal operations [integrity]	TSR_04_01_SW	The safety engine shall verify continuously that the integrity of input data from the IMU is corrupted or not. Integrity can be verified based on: <ul style="list-style-type: none"> • Output register checks • Control register checks • ODR checks
SW_REQ_04	Data from IMU shall be verified in terms of accuracy and alignment with datasheet boundaries [accuracy]	TSR_04_02_SW	The safety engine shall check the accuracy of the input data from the IMUs, relating in particular on the evolution over time of: <ul style="list-style-type: none"> • Sensor bias and norm • Sensitivity variations • Data stuck and quasi-stuck • Cross-correlation between sensors data
SW_REQ_05	Software diagnostics shall be guaranteed and provided at the input of the SMU [diagnostic]	TSR_03_01_SW TSR_04_03_SW	The safety engine shall run the overall diagnostic in order to guarantee explicit information at the output. Any failure at diagnostic level must be avoided: <ul style="list-style-type: none"> • Safe coding • ISO guidelines


Note: The integrity and accuracy of the input data can be only checked and not retrieved in case of failures.

3.1 Software architecture – low-level requirements

The defined software architecture is illustrated in Figure 2. Preliminary software architecture, where it is shown the diagnostic and alarm function block able to expose at the output an error code mechanism aligned with the data provided by the sensors. With reference to this architecture, the list of low-level software requirements / safety mechanisms is distinguished in:

- **[ISC safety mechanisms - integrity]** run at *startup* during BOOT and system offline.
- **[IRC safety mechanisms - integrity]** run at *runtime* during normal operation.
- **[ARC safety mechanisms - accuracy]** run at *runtime* during normal operation, also exploiting sensor redundancy.

Figure 2. Preliminary software architecture



The system integrator should confirm the adequacy of the mechanisms provided, within the resulting failure mode coverage, by the software library in the context of the specific system level analysis.

3.1.1 Initial checks and configuration

To ensure the absence of latent faults, a series of operations are processed during boot while the device is stationary after reset.

[ISC_SM_01 – Accelerometer/gyroscope self-test][SW_REQ_02]

When the accelerometer self-test is enabled, an actuation force is applied to the sensor, simulating a defined input acceleration. In this case, the sensor outputs exhibit a change in their DC levels, which are related to the selected full-scale through the sensitivity value.

At startup, with the vehicle stationary and engine off, the library is able to perform in cascade the accelerometer and gyroscope self-test procedures with an alternate scheme for the two sensors as follows:

- Self-test applied on 5 samples of XL_IMU_1 + contextual stationary check on IMU_2
- Self-test applied on 5 samples of XL_IMU_2 + contextual stationary check on IMU_1
- Self-test applied on 5 samples of GYRO_IMU_1 + contextual stationary check on IMU_2
- Self-test applied on 5 samples of GYRO_IMU_2 + contextual stationary check on IMU_1

To perform this mechanism, the library configures the accelerometer sensors at 52 Hz with FS = $\pm 4\text{ g}$ and the gyroscope sensors at 52 Hz with FS = $\pm 2000\text{ dps}$.

The thresholds used by the library to evaluate a stationary state are configured by the user through the “acc_still_ths” threshold for the accelerometer and “gyr_still_ths” threshold for the gyroscope, while the thresholds to evaluate the self-tests are the low and high limits indicated in the datasheet.

If the condition on the stationary check fails, a specific error code is provided as ERR_ST_ACC_NOT_STILL. In the case of verified stationary condition but failing self-test output, the specific error code is generated as ERR_ST_ACC_FAIL.

[ISC_SM_02 – IMU STATUS][SW_REQ_01]

At startup, with the vehicle stationary and the engine off, the library is able to perform a check on the connected device along with its ID and the OTP correct loading, in turn used to confirm the correct BOOT procedure. Both checks are implemented with a safe-read function and the return value therein implemented:

- ERR_DEV_ID in case of NULL return from the WHOAMI safe_read function.
- ERR_BOOT_FAIL in case of NULL return from the STATUS REGISTER safe_read function.

[ISC_SM_03 – XLnorm_init][SW_REQ_02]

Data buffers derived from the accelerometer self-test procedure can be used at startup to evaluate the norm of the accelerometer. The contextual check for IMU stationary condition is used to validate the comparison of the computed norm with a threshold derived from the datasheet specifications.

In particular, if the absolute value of the difference between the smoothed norm and 1.0 g exceeds a threshold (0.319808 g for ASM330LHB, 0.406411 g for ASM330LHBG1), the ERR_ACC_BIAS error is generated and returned. This threshold is based on the datasheet parameters called LA_Off long term and LA_So% long term.

[ISC_SM_04 – GBias_init][SW_REQ_02]

Data buffers derived from the gyroscope self-test procedure can be used at startup to evaluate the bias on each axis of the gyroscope. The contextual check for IMU stationary condition is used to validate the comparison of the computed biases with the thresholds derived from the datasheet specifications.

In particular, if the absolute value of any of the smoothed gyroscope axes exceeds a threshold (7 dps for ASM330LHB, 10 dps for ASM330LHBG1, refer to the G_Off - long term parameter in the datasheet), the ERR_GYR_BIAS error is generated and returned

[ISC_SM_05 – Params Check] [SW_REQ_02]

The configuration structure filled in by the user is verified through plausibility checks and min-max ranges aligned with expected values. In the case of verified values outside the expected range, the ERR_PARAM error code is provided in the diagnostic output.

3.1.2 Runtime integrity checks

Data integrity can be verified at runtime by evaluating the output data registers and their refresh rate, along with detecting communication issues.

[IRC_SM/INT_02 – Clock/ODR monitoring][SW_REQ_03]

If the INT mode is enabled, the library implements a dedicated check on the refresh rate of the incoming data. The GDA and XLDA bits of STATUS REG (1Eh) are used. In the case of missing refresh data or a DTIME outside the range specified in the configuration sensor register, the error codes are provided as ERR_DATA_READY and ERR_DTIME.

[IRC_SM_03 – CTRL registers monitoring][SW_REQ_03]

At runtime, it is possible to evaluate any undesired changes of sensor configurations and validate the integrity of the associated registers. This can be done with the continuous dump of the CTRL registers during normal operation. This is done within FTTI constraints and the related error code ERR_CTRL is provided in case of unintended registers access/change.

[IRC_SM_04 – COMM diagnostic][SW_REQ_03]

At runtime, after the init check for IMU STATUS with the mechanism [ISC_SM_02], the library is able to perform a detection of any kind of communication loss including accelerometer/gyroscope sensor data loss. In this case, the failure is considered as not permanent if a connection or data presence is re-established during data processing. The library provides within the same FTTI the error code ERR_COMM in this case.

[IRC_SM_05 – Stuck monitoring][SW_REQ_03]

The library implements an algorithm to evaluate if the signal of both the IMUs results in being stuck at a value. Detection of the stuck signal is based on a defined number of samples, and a counter for how many samples are replicated for all the sensor axes at the same time and a specific error code ERR_STUCK is provided from the library within FTTI.

[IRC_SM_06 – RESET][SW_REQ_03]

An unexpected/undesired hard reset of the sensors for both the IMUs is detected by the library with a defined compare of control registers at runtime. Any unexpected reset results in the loading of the default configuration, and the ERR_RESET code is provided from the library.

[IRC_SM_07 – SRC][SW_REQ_03]

If enabled by the user through the src_en flag parameter, the library implements a CRC-like mechanism with multiple reads of the same data. In the case of inconsistency of read data, the ERR_SRC error flag is provided at the output of the diagnostic output.

3.1.3 Runtime accuracy checks

Data accuracy refers to the capability of the IMU to provide data that are correlated with the physical inputs (acceleration and angular speed) as described in the datasheet specifications.

[ARC_SM_01 – FS out of range][SW_REQ_04]

At runtime, the library is able to detect if the output of the IMUs has reached the saturation value or even more in relation to the set FS parameter (saturation value inside the library is set equal to 32764 LSB). In this case, the ERR_ACC_SAT/ERR_GYR_SAT error codes are provided.

[ARC_SM_02 – BIAS monitoring][SW_REQ_04]

At runtime, for both the IMUs, an evaluation of the bias for both the accelerometer and gyroscope is performed. In this case, because the validity of the computed output depends on the knowledge of the stationary condition, an input is required in order to trigger the algorithm chain. In particular, a binary flag steady/not steady is mandatory to validate the output and the possible fault detection with the ERR_BIAS error codes.

[ARC_SM_03 – Q-Stuck monitoring][SW_REQ_04]

At runtime, the library is able to detect if the two IMUs present a signal defined as quasi-stuck, meaning that the output is stuck at a constant value with small oscillations around this value.

[ARC_SM_04 – Pulse transition][SW_REQ_04]

At runtime, the accelerometer and gyroscope signals of both the IMUs is verified in relation to the presence of single and repetitive spikes.

[ARC_SM_05 – Redundancy][SW_REQ_04]

The redundancy mechanism is used to evaluate the deviation on the output of both the accelerometer and gyroscope with an RMSE metric applied to a buffer of N samples considering a time window of 100 ms. If the computed RMSE value is above the defined threshold, the error code ERR_ACC_REDUNDANCY/ERR_GYR_REDUNDANCY is provided. Within this mechanism, it is possible to provide information relative to sensitivity faults in one of the IMUs and, in general, a fault in the sensing chain.

[COD – Coding][SW_REQ_05]

The library is developed according to the guidelines of ASIL-B compliancy in order to guarantee minimization or absence of systematic failures that can influence the correct capability of generating the required diagnostic output.

Note also that in accordance with the [ARC_SM_02 – BIAS monitoring] mechanism, the biases of the accelerometer and gyroscope sensor cannot be evaluated while the vehicle is moving. This generated the following assumption.

Assumption #19: It is assumed that a required input of the library is a flag for a stationary vehicle. If the vehicle is stationary, the bias check mechanisms are active, otherwise they are automatically disabled.

The following table provides an example of the list of error codes with description and output mask.

Table 3. Sample error codes

Error Code	Mask	Description
ERR_NONE	0x0000000000000000ULL	No error
ERR_COMM_0	0x0000000000000001ULL	Communication error (imu id = 0)
ERR_READ_BACK_0	0x0000000000000002ULL	Read back error (imu id = 0)
ERR_DEV_ID_0	0x0000000000000004ULL	Device ID check error (imu id = 0)
ERR_BOOT_FAIL_0	0x0000000000000008ULL	Device boot error (imu id = 0)
ERR_ST_ACC_FAIL_0	0x0000000000000010ULL	Accelerometer self-test failed (imu id = 0)
ERR_ST_GYR_FAIL_0	0x0000000000000020ULL	Gyroscope self-test failed (imu id = 0)
ERR_ST_ACC_NOT_STILL_0	0x0000000000000040ULL	Accelerometer not stationary during self-test (imu id = 0)
ERR_ST_GYR_NOT_STILL_0	0x0000000000000080ULL	Gyroscope not stationary during self-test (imu id = 0)
ERR_CTRL_REG_0	0x0000000000000100ULL	Device configuration integrity error (imu id = 0)
ERR_RESET_0	0x0000000000000200ULL	Device unexpected reset error (imu id = 0)
ERR_ACC_SAT_0	0x0000000000000400ULL	Accelerometer saturation error (imu id = 0)
ERR_GYR_SAT_0	0x0000000000000800ULL	Gyroscope saturation error (imu id = 0)
ERR_ACC_STUCK_0	0x0000000000001000ULL	Accelerometer is stuck (imu id = 0)
ERR_GYR_STUCK_0	0x0000000000002000ULL	Gyroscope is stuck (imu id = 0)
ERR_ACC_PULSE_0	0x0000000000004000ULL	Accelerometer pulse error (imu id = 0)
ERR_GYR_PULSE_0	0x0000000000008000ULL	Gyroscope pulse error (imu id = 0)
ERR_ACC_BIAS_0	0x0000000000010000ULL	Accelerometer bias error (imu id = 0)
ERR_GYR_BIAS_0	0x0000000000020000ULL	Gyroscope bias error (imu id = 0)
ERR_ACC_QUASI_STUCK_0	0x0000000000040000ULL	Accelerometer quasi stuck error (imu id = 0)
ERR_GYR_QUASI_STUCK_0	0x0000000000080000ULL	Gyroscope quasi stuck error (imu id = 0)
ERR_SRC_0	0x0000000000010000ULL	Sample redundancy check error (imu id = 0)
ERR_COMM_1	(ERR_COMM_0 << 32ULL)	Communication error (imu id = 1)
ERR_READ_BACK_1	(ERR_READ_BACK_0 << 32ULL)	Read back error (imu id = 1)
ERR_DEV_ID_1	(ERR_DEV_ID_0 << 32ULL)	Device ID check error (imu id = 1)
ERR_BOOT_FAIL_1	(ERR_BOOT_FAIL_0 << 32ULL)	Device boot error (imu id = 1)
ERR_ST_ACC_FAIL_1	(ERR_ST_ACC_FAIL_0 << 32ULL)	Accelerometer self-test failed (imu id = 1)
ERR_ST_GYR_FAIL_1	(ERR_ST_GYR_FAIL_0 << 32ULL)	Gyroscope self-test failed (imu id = 1)
ERR_ST_ACC_NOT_STILL_1	(ERR_ST_ACC_NOT_STILL_0 << 32ULL)	Accelerometer not stationary during self-test (imu id = 1)
ERR_ST_GYR_NOT_STILL_1	(ERR_ST_GYR_NOT_STILL_0 << 32ULL)	Gyroscope not stationary during self-test (imu id = 1)
ERR_CTRL_REG_1	(ERR_CTRL_REG_0 << 32ULL)	Device configuration integrity error (imu id = 1)
ERR_RESET_1	(ERR_RESET_0 << 32ULL)	Device unexpected reset error (imu id = 1)
ERR_ACC_SAT_1	(ERR_ACC_SAT_0 << 32ULL)	Accelerometer saturation error (imu id = 1)
ERR_GYR_SAT_1	(ERR_GYR_SAT_0 << 32ULL)	Gyroscope saturation error (imu id = 1)
ERR_ACC_STUCK_1	(ERR_ACC_STUCK_0 << 32ULL)	Accelerometer is stuck (imu id = 1)
ERR_GYR_STUCK_1	(ERR_GYR_STUCK_0 << 32ULL)	Gyroscope is stuck (imu id = 1)
ERR_ACC_PULSE_1	(ERR_ACC_PULSE_0 << 32ULL)	Accelerometer pulse error (imu id = 1)
ERR_GYR_PULSE_1	(ERR_GYR_PULSE_0 << 32ULL)	Gyroscope pulse error (imu id = 1)
ERR_ACC_BIAS_1	(ERR_ACC_BIAS_0 << 32ULL)	Accelerometer bias error (imu id = 1)
ERR_GYR_BIAS_1	(ERR_GYR_BIAS_0 << 32ULL)	Gyroscope bias error (imu id = 1)

Error Code	Mask	Description
ERR_ACC_QUASI_STUCK_1	(ERR_ACC_QUASI_STUCK_0 << 32ULL)	Accelerometer quasi stuck error (imu id = 1)
ERR_GYR_QUASI_STUCK_1	(ERR_GYR_QUASI_STUCK_0 << 32ULL)	Gyroscope quasi stuck error (imu id = 1)
ERR_SRC_1	(ERR_SRC_0 << 32ULL)	Sample redundancy check error (imu id = 1)
ERR_INTERNAL	0x0200000000000000ULL	Internal error
ERR_TIMEOUT	0x0400000000000000ULL	Data-ready polling timeout error
ERR_DATA_READY	0x0800000000000000ULL	Data-ready not updated error
ERR_DTIME	0x1000000000000000ULL	Delta-time error
ERR_PARAM	0x2000000000000000ULL	Invalid parameter error
ERR_ACC_REDUNDANCY	0x4000000000000000ULL	Accelerometer redundancy error
ERR_GYR_REDUNDANCY	0x8000000000000000ULL	Gyroscope redundancy error

3.2 Enabling safety mechanisms and software APIs

The compiled library assures compliancy to the ASIL-B safety level with the whole set of the implemented safety mechanisms. This means that the user cannot disable a subset of these features or choose one that is the most suitable for his purposes.

The library is shared in binary format along with its header file. The exported APIs and the library parameters are included. Each API returns an integer containing the error code.

3.2.1 Initialization

The library is initialized by calling the *ab_init* function. It takes as input a structure with the configuration to be set in the library. All the configuration parameters must be set before calling the *ab_init* function.

The structure containing the configuration parameters is shown below.

```
/**
 * @brief Library configuration data structure.
 * @details Contain the library parameters that can be configured.
 */
struct ab {
  uint8_t device; /**< @brief Device code. */
  uint8_t interface; /**< @brief Interface code. */
  uint8_t odr; /**< @brief Output data rate code. */
  uint8_t acc_fs; /**< @brief Accelerometer full-scale code. */
  uint8_t gyr_fs; /**< @brief Gyroscope full-scale code. */
  int8_t acc_lpf; /**< @brief Accelerometer LPF2 configuration (acc_lpf = -1 to disable). */
  int8_t gyr_lpf; /**< @brief Gyroscope LPF1 configuration (gyr_lpf = -1 to disable). */
  uint8_t int_pin; /**< @brief Interrupt pin configuration code. */
  float tim_freq; /**< @brief Timer frequency [Hz]. */
  int16_t rot0[3][3]; /**< @brief Rotation matrix to be applied to primary sensor data (imu id = 0). */
  int16_t rot1[3][3]; /**< @brief Rotation matrix to be applied to secondary sensor data (imu id = 1). */
  float acc_still_ths; /**< @brief Accelerometer stillness threshold [g] during @ref ab_checkup. */
  float gyr_still_ths; /**< @brief Gyroscope stillness threshold [dps] during @ref ab_checkup. */
  float acc_red_ths; /**< @brief Accelerometer redundancy threshold [g]. */
  float gyr_red_ths; /**< @brief Gyroscope redundancy threshold [dps]. */
  float acc_pul_ths; /**< @brief Accelerometer pulse threshold [g]. */
  float gyr_pul_ths; /**< @brief Gyroscope pulse threshold [dps]. */
  float acc_qs_ths; /**< @brief Accelerometer quasi stuck threshold [g]. */
  float gyr_qs_ths; /**< @brief Gyroscope quasi stuck threshold [dps]. */
  uint8_t src_en; /**< @brief Sample redundancy check enable. */
  uint8_t poll_dis; /**< @brief Data-ready polling disable during devices check-up. */
  uint64_t (*write)(uint8_t id, uint8_t addr, uint8_t val); /**< @brief Function pointer for writing data to devices. */
  uint64_t (*read)(uint8_t id, uint8_t addr, uint8_t *val, uint16_t len); /**< @brief Function pointer for reading data from devices. */
  uint32_t (*systick)(void); /**< @brief Function pointer for getting system tick [ms]. */
  void (*delay)(uint32_t delay); /**< @brief Function pointer for generating a delay [ms]. */
  void (*calibrate)(uint8_t id, struct ab_data_f *out, const struct ab_data_f *in); /**< @brief Function pointer for applying calibration. */
};
```

A brief description of them is as follows:

- **device:** device configuration. It can be set to ASM330LHB or ASM330LHBG1.
- **interface:** interface configuration. It can be set to I²C, MIPI I3C, SPI 3-wire, or SPI 4-wire.
- **odr:** output data rate configuration. It can be set to 52 Hz, 104 Hz, 208 Hz, 417 Hz, 833 Hz, 1667 Hz, 3333 Hz, 6667 Hz. The 3333 Hz and the 6667 Hz output data rates are available only if the timer (TIM mode, that is, the *int_pin* parameter of the configuration structure is set to INT_NONE) or the external trigger is used (DEN mode, that is, the *int_pin* parameter of the configuration structure is set to INT_DEN_L or INT_DEN_H).
- **acc_fs:** accelerometer full-scale configuration. It can be set to $\pm 2\text{ g}$, $\pm 4\text{ g}$, $\pm 8\text{ g}$, $\pm 16\text{ g}$.
- **gyr_fs:** gyroscope full-scale configuration. It can be set to $\pm 125\text{ dps}$, $\pm 250\text{ dps}$, $\pm 500\text{ dps}$, $\pm 1000\text{ dps}$, $\pm 2000\text{ dps}$, $\pm 4000\text{ dps}$.
- **acc_lpf:** accelerometer LPF2 configuration. It can be set from -1 to 7. If it is set to -1, the LPF2 filter is disabled, otherwise the corresponding filter configuration is applied.
- **gyr_lpf:** Gyroscope LPF1 configuration. It can be set in the range from -1 to 7 if “odr” is lower than or equal to ODR_1667HZ, or it must be in the range from -1 to 3 if “odr” is equal to ODR_3333HZ or ODR_6667HZ. If it is set to -1, the LPF1 filter is disabled, otherwise the corresponding filter configuration is applied.
- **int_pin:** interrupt pin configuration. It can be set to INT_NONE (if no interrupt pin connected to the host), INT1 (primary sensor INT1 pin used), INT2 (primary sensor INT2 pin used), INT3 (secondary sensor INT1 pin used), INT4 (secondary sensor INT2 pin used), INT_DEN_L (primary and secondary sensor INT2 pins used as input for active-low external trigger), INT_DEN_H (primary and secondary sensor INT2 pins used as input for active-high external trigger).
- **tim_freq:** timer or external trigger frequency configuration. It must be set when the interrupt pin is not used (the *int_pin* parameter of the configuration structure is set to INT_NONE) or the external trigger is used (the *int_pin* parameter of the configuration structure is set to INT_DEN_L or INT_DEN_H). It must be in the range [50, 1500] Hz. It must be lower than the selected output data rate (*odr*).
- **rot0:** rotation matrix to be applied to primary sensor data. Note: primary and secondary sensor data must be aligned after the rotation.

- **rot1**: rotation matrix to be applied to secondary sensor data. Note: primary and secondary sensor data must be aligned after the rotation.
- **acc_still_ths**: accelerometer sensor stillness threshold used during check-up phase, expressed in *g*. The threshold is applied to the accelerometer diff signals.
Assumption #25: It is assumed that the customers configure threshold **acc_still_ths** based on their applicative scenario.
- **gyr_still_ths**: gyroscope sensor stillness threshold used during check-up phase, expressed in *dps*. The threshold is applied to the gyroscope diff signals.
Assumption #26: It is assumed that the customers configure threshold **gyr_still_ths** based on their applicative scenario.
- **acc_red_ths**: accelerometer sensor redundancy threshold, expressed in *g*.
- **gyr_red_ths**: gyroscope sensor redundancy threshold, expressed in *dps*.
- **acc_pul_ths**: accelerometer sensor pulse threshold, expressed in *g*.
- **gyr_pul_ths**: gyroscope sensor pulse threshold, expressed in *dps*.
- **acc_qs_ths**: accelerometer sensor quasi stuck threshold, expressed in *g*. If **acc_qs_ths** = 0, the quasi stuck check is disabled.
- **gyr_qs_ths**: gyroscope sensor quasi stuck threshold, expressed in *dps*. If **gyr_qs_ths** = 0, the quasi stuck check is disabled.
- **src_en**: flag to enable the sample redundancy check (SRC). If **src_en** = 1, the SRC is enabled.
- **poll_dis**: flag to disable the data-ready signal polling during devices check-up. If **poll_dis** = 1, the data-ready signal polling is disabled.
- **write**: pointer to the function for writing data to both the devices. It must be implemented by the user and takes the following parameters:
 - *id*, identifier of the sensor (0 is the primary sensor, 1 is the secondary sensor)
 - *addr*, device register to be written
 - *val*, value to be written in *addr* device register

It must return the communication error code if the communication fails.

- **read**: pointer to the function for reading data from both the devices. It must be implemented by the user and takes the following parameters:
 - *id*, identifier of the sensor (0 is the primary sensor, 1 is the secondary sensor)
 - *addr*, device register to be read
 - *val*, pointer to the buffer where the data read starting from *addr* device register are stored

It must return the communication error code if the communication fails.

- **systick**: pointer to the function for getting system tick, expressed in milliseconds
- **delay**: pointer to the function for generating a delay, expressed in milliseconds
- **calibrate**: pointer to the function for applying sensor data calibration for the redundancy mechanisms. It must be implemented by the user and takes the following parameters:
 - *id*, identifier of the sensor (0 is the primary sensor, 1 is the secondary sensor)
 - *out*, pointer to the structure where the output calibrated data must be written to
 - *in*, pointer to the structure containing the input uncalibrated data

The *ab_init* function checks the configuration, applies the configuration, and performs the device reboot and software reset, device communication check, and device boot status check. It implements the following safety mechanisms:

- Connection check (by reading the WHO_AM_I register of the device)
- Boot status check (no fail loading OTP configuration)

3.2.2 Checkup

After the library initialization, the *ab_checkup* function must be called in order to verify that both the sensors are operating according to the specifications. The *ab_checkup* function implements the **[ISC]** safety mechanisms:

- Accelerometer self-test
- Gyroscope self-test
- Accelerometer norm bias check
- Gyroscope bias check

The *ab_checkup* function returns without error if the devices are steady and operating according to the specifications.

3.2.3 Start/Stop

After the sensors have been checked, the *ab_start* function must be called in order to turn the sensors on with the configuration selected by the user.

The *ab_stop* function can be called in order to turn the sensors off.

3.2.4 Process

After the sensors have been turned on, the *ab_process* function must be called in one of the following ways:

- In the configured interrupt callback (or high priority task triggered by the configured interrupt), if the **int_pin** parameter of the configuration structure is set to INT1, INT2, INT3, or INT4 (that is, one interrupt pin is connected to the host and used to provide data-ready signal). The *ab_process* function must be completely executed before receiving the next interrupt callback: it is required to ensure an execution time lower than $1 / (\text{ODR} + 10\%)$.
- In a timer callback (or high priority task triggered by the timer), if the **int_pin** parameter of the configuration structure is set to INT_NONE. The timer must be configured to elapse at a desired pace (lower than the selected ODR). The *ab_process* function must be completely executed before receiving the next timer callback.
- In a callback corresponding to the external trigger event (or high priority task triggered by the external trigger event), if the **int_pin** parameter of the configuration structure is set to INT_DEN_L or INT_DEN_H. The external trigger must be configured to be generated at a desired pace (lower than the selected ODR). The *ab_process* function must be completely executed before receiving the next external trigger.

In the *ab_process* function, sensors data are read, and runtime safety mechanisms are executed. If the interrupt pin is configured, the time between two consecutive interrupt callbacks (that is, delta-time or dtime) must be measured and passed to the *ab_process* function as input, expressed in microseconds. If the interrupt pin is not configured (that is, **int_pin** is set to INT_NONE) or the external trigger is used (that is, **int_pin** is set to INT_DEN_L or INT_DEN_H), the dtime input parameter is not used by the *ab_process* function. The *ab_process* function implements the whole set of **[IRC]** and **[ARC]** safety mechanisms. The user can get the latest sensor data (both or either of them) by calling the *ab_get_data* function. The returned data are rotated based on *rot0* and *rot1* rotation matrices. If the user is not interested in getting the primary or secondary sensor data, it can pass NULL pointer to the *ab_get_data* function as input parameter. The bias of the accelerometer and gyroscope sensors cannot be evaluated while moving. For this reason, the user must specify in the library if the vehicle is stationary or not. If the vehicle is stationary, the bias check mechanisms are active, otherwise they are inactive.

3.2.5 Tuning

The `ab_get_tuning_data` function is called by the user to retrieve the current limits (maximum or minimum values) to tune the thresholds for quasi-stuck, pulse, and redundancy software safety mechanisms. Such a procedure should be repeated in several application scenarios and with a statistically significant sample of different devices in order to cover part-to-part variability effects and environmental effects.

Assumption #20: It is assumed that the customer performs the *Tuning* procedure to properly configure the thresholds with attention to the specific vehicle, application scenarios, and part-to-part population variability, so that quasi-stuck, pulse, and redundancy software safety mechanisms work as they are intended and are robustly managing expected intrinsic product variability and application environment effects.

In particular, the thresholds that are defined in the `ab_struct` function are shown in [Table 5](#).

Table 4. Configurable thresholds of quasi-stuck, pulse, and redundancy software safety mechanisms

Software safety mechanism	Configurable threshold	About the threshold
ARC_SM_03 – Q-Stuck monitoring	<code>acc_qs_ths</code>	accelerometer sensor quasi-stuck threshold, expressed in [g]. If <code>acc_qs_ths</code> = 0, the quasi-stuck check is disabled.
ARC_SM_03 – Q-Stuck monitoring	<code>gyr_qs_ths</code>	gyroscope sensor quasi-stuck threshold, expressed in [dps]. If <code>gyr_qs_ths</code> = 0, the quasi-stuck check is disabled.
ARC_SM_04 – Pulse transition	<code>acc_pul_ths</code>	accelerometer sensor pulse threshold, expressed in [g]
ARC_SM_04 – Pulse transition	<code>gyr_pul_ths</code>	gyroscope sensor pulse threshold, expressed in [dps]
ARC_SM_05 – Redundancy	<code>acc_red_ths</code>	accelerometer sensor redundancy threshold, expressed in [g]
ARC_SM_05 – Redundancy	<code>gyr_red_ths</code>	gyroscope sensor redundancy threshold, expressed in [dps]

The generalization of the PCB layout and the specific needs of the customer may require a dedicated tuning of the above thresholds. To better detail these values, the user may benefit from the following addendum.

- The variables `acc_qs_ths` and `gyr_qs_ths` refer to the level of signal oscillation that can be recognized as unreliable for the noise characteristics of the sensor.
- The variables `acc_pul_ths` and `gyr_pul_ths` refer to the allowed maximum amplitude of spikes occurring for the output signal. This value can be considered constant for the same device part number, but it can be refined according to the specific setup and environmental conditions.
- For the variables `acc_red_ths` and `gyr_red_ths`, the mechanism implements a check on the redundancy/correlation value derived from the signals of IMU0 and IMU1. The computed value can vary due to the distance of the sensors and environmental conditions.

The tuning process is implemented as follows:

- The library is run for the desired time and for the desired number of times.
- The tuning data (limits that are the maximum or minimum values) are collected at the end of every run by calling API `ab_get_tuning_data`.

- The thresholds are computed as follows:
 - For the quasi-stuck checks, the minimum collected value is chosen and a tolerance is applied to it (for example, the minimum value is decreased by the desired tolerance (%)).
 - For the pulse checks, the maximum collected value is chosen and a tolerance is applied to it (for example, the maximum values is increased by the desired tolerance (%)).
 - For the redundancy checks, choose the maximum collected value and apply a tolerance to it. For example, the maximum collected value is increased by the desired tolerance (%), which depends on the customer's application scenario and by a tolerance (part-to-part) defined according to the datasheet and which is equal to:
 - For the calculation of *acc_red_ths*:
 - If the selected device is ASM330LHB, the tolerance (part to part) is equal to 300 mg + 12 % of the maximum signal that the user's application can sense.
 - If the selected device is ASM330LHBG1, the tolerance (part-to-part) is equal 400 mg + 12 % of the maximum signal that the user's application can sense.
 - For the calculation of *gyr_red_ths*:
 - If the selected device is ASM330LHB, the tolerance (part-to-part) is equal to 14 dps + 16 % of the maximum signal that the user's application can sense.
 - If the selected device is ASM330LHBG1, the tolerance (part to part) is equal to 20 dps + 20 % of the maximum signal that the user's application can sense.

The method to tune the thresholds is summarized in [Table 5](#).

Table 5. Method to properly configure the thresholds of quasi-stuck, pulse, and redundancy software safety mechanisms

Logged parameter [per run k]	Variable to be tuned	Method
<i>acc_qs(k)</i>	<i>acc_qs_ths</i>	$acc_qs_ths = \min_1^k(acc_qs_k) - tolerance_{\%}$
<i>gyr_qs(k)</i>	<i>gyr_qs_ths</i>	$gyr_qs_ths = \min_1^k(gyr_qs_k) - tolerance_{\%}$
<i>acc_pul(k)</i>	<i>acc_pul_ths</i>	$acc_pul_ths = \max_1^k(acc_pul_k) + tolerance_{\%}$
<i>gyr_pul(k)</i>	<i>gyr_pul_ths</i>	$gyr_pul_ths = \max_1^k(gyr_pul_k) + tolerance_{\%}$
<i>acc_red(k)</i>	<i>acc_red_ths</i>	$acc_red_ths = \max_1^k(acc_red_k) + tolerance_{\%} + tolerance_{part\ to\ part}$
<i>gyr_red(k)</i>	<i>gyr_red_ths</i>	$gyr_red_ths = \max_1^k(gyr_red_k) + tolerance_{\%} + tolerance_{part\ to\ part}$

Assumption #21: It is assumed that the desired tolerances to be added to the limits retrieved by using the *ab_get_tuning_data* function (maximum or minimum values) strongly depend on the customer's application scenario and they are such that false positives are avoided.

3.3 Safety library resources

The safety engine can be integrated in a host MCU of any kind of architecture provided by the customer along with used compiler and compilation options. In addition, it supports multi-instance, allowing interfacing more than one pair of devices with the same host. Each instance is not dependent on the other instances. By default, the library is compiled and released for supporting two instances, that is, two pairs of two IMUs, for a total of four IMUs. The safety engine can be compiled and released for supporting just a single instance or more than two instances based on customer request.

The access of the end user is limited to the *struct ab*, with the setting of all included thresholds. Regarding the minimum requirements in terms of resources, these are summarized as:

- Exec time < $1/(\text{ODR} + 10\%)$ ms
- Benchmark using STM32F401VE @ 84 MHz, 32-bit architecture with single precision FPU (Cortex-M4F)
- The benchmark results vary based on the library configuration, compiler, and compiling switches

Library footprint:

- *ROM*
 - From a minimum of ~10 KB to a maximum of ~20 KB
- *RAM*
 - 8 KB per instance (8 KB for one instance only, 16 KB for two instances, and so forth), where one instance manages two IMUs
 - Additional stack usage is ~2 KB
- *Execution time (including data reading with SPI at 10 MHz)*
 - INT or TIM mode takes about 280 μ s
 - DEN mode at 6667 Hz takes about 300-450 μ s

Assumption #22: It is assumed that the integrated safety engine, specifically the *ab_process* function, must be completely executed.

- In the case of an interrupt connection, before receiving the next interrupt callback, it is required to ensure an execution time lower than $1 / (\text{ODR} + 10\%)$.
- In the case of a timer callback, before receiving the next timer callback, with the timer configured to elapse at a desired rate (lower than the selected ODR).
- In the case of a callback corresponding to the external trigger event (or high priority task triggered by the external trigger event), the external trigger must be configured to be generated at a desired pace (lower than the selected ODR) and the *ab_process* function must be completely executed before receiving the next external trigger.

Assumption #23: It is assumed that time interleaving between two consecutive data-ready signals must be measured by the user (for example, using a timer configured in input capture mode). It is also assumed that the time measurement provided by the user has a maximum error of $\pm 1\%$.

Assumption #24: The object file of the safety engine was compiled using IAR Embedded Workbench® (EWARM) for Arm® v9.10.2, whose confidence has been properly assessed for the use in this project according to ISO 26262-8:2018 clause 11. It is assumed that in case a different compiler is used, an impact analysis is required. Further verification/confirmation activities may be needed to confirm the achievement of functional safety.

Appendix A Abbreviations

The following abbreviations are used throughout this document.

A	
ASIL	Automotive safety integrity level
D	
DTTI	Diagnostic test time interval
F	
FMEA	Failure mode and effect analysis
FSC	Functional safety concept
FPU	Floating point unit
FTTI	Fault tolerant time interval
H	
HARA	Hazard analysis and risk assessment
I	
IMU	Inertial measurement unit
M	
MCU	Microcontroller unit
S	
SEooC	Safety Element out of Context
SMU	Sensor management unit
T	
TSC	Technical safety concept

Revision history

Table 6. Document revision history

Date	Version	Changes
24-Feb-2023	5	First public release
17-May-2024	6	Updated Section 3.1.1: Initial checks and configuration , Section 3.2.1: Initialization , Section 3.2.4: Process , and Section 3.3: Safety library resources Added ERR_INTERNAL to Table 3. Sample error codes

Contents

1	SEooC overview	2
1.1	SEooC architecture	2
1.2	Basic assumptions	3
2	Safety concept	4
2.1	Assumed safety goals	4
2.2	Failure mode analysis	5
2.3	Assumed functional safety requirements	6
2.4	Assumed technical safety concept	7
2.4.1	Allocation of safety requirements	8
2.5	Avoidance of systematic failures	9
2.5.1	Software failure modes and ISO coding guidelines	9
2.5.2	Software freedom from interference	9
2.6	Random failure modes and safety mechanisms	10
3	Software development	11
3.1	Software architecture – low-level requirements	12
3.1.1	Initial checks and configuration	12
3.1.2	Runtime integrity checks	14
3.1.3	Runtime accuracy checks	15
3.2	Enabling safety mechanisms and software APIs	18
3.2.1	Initialization	18
3.2.2	Checkup	20
3.2.3	Start/Stop	20
3.2.4	Process	20
3.2.5	Tuning	21
3.3	Safety library resources	23
Appendix A Abbreviations		24
Revision history		25
List of tables		27
List of figures		28

List of tables

Table 1.	Extract of coding guidelines.	9
Table 2.	SEooC high-level software safety requirements	11
Table 3.	Sample error codes	16
Table 4.	Configurable thresholds of quasi-stuck, pulse, and redundancy software safety mechanisms.	21
Table 5.	Method to properly configure the thresholds of quasi-stuck, pulse, and redundancy software safety mechanisms.	22
Table 6.	Document revision history	25

List of figures

Figure 1.	System block diagram in which the SEooC has been developed	2
Figure 2.	Preliminary software architecture	12

IMPORTANT NOTICE – READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgment.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2024 STMicroelectronics – All rights reserved